

Interface Control Document  
RW-0.003 Tiny Reaction Wheels  
Doug Sinclair, Cordell Grant, May 27, 2020  
Rev 1.0

1	Scope.....	4
2	Mechanical.....	4
2.1	Overall Dimensions.....	4
2.2	Mounting Holes.....	5
2.3	Mass Properties .....	6
2.4	Remove Before Flight .....	6
3	Environmental.....	6
3.1	Storage.....	6
3.2	Thermal .....	6
3.3	Pressure .....	6
3.4	Vibration.....	6
4	Electrical .....	6
4.1	Polarized Nano .....	6
4.2	Programming Header .....	7
5	Signals.....	7
5.1	Power In/Out .....	7
5.2	Ground.....	7
5.3	SDA, SCL.....	7
5.4	C2CK.....	8
5.5	Power Architecture.....	8
5.6	Regenerative Braking.....	8
6	Protocol Layer 2 (Data Link Layer).....	9
6.1	I <sup>2</sup> C.....	9
6.2	Asynchronous Serial .....	9
7	Protocol Layer 3 (Network Layer).....	9
7.1	SLIP Encoding .....	9
7.2	I <sup>2</sup> C Encapsulation.....	9
8	Protocol Layer 4 (Transport Layer) .....	10
8.1	NSP Message Format .....	10
8.2	NSP Addresses .....	11
8.3	Message Control Field .....	11
8.4	Data Field .....	12
8.5	Message CRC.....	12
8.6	Error Conditions.....	12
9	Protocol Layer 5 (Session Layer) .....	12
9.1	Operating Modes .....	12
9.1.1	Bootloader to Application Transition .....	13
9.1.2	Application to Bootloader Transition .....	13
9.2	Test Scripts.....	13
9.3	Byte Order .....	13
9.4	Command Codes .....	13

9.5	PING (0x00)	14
9.5.1	Command Format	14
9.5.2	Reply Format	14
9.6	INIT (0x01)	14
9.6.1	Command Format	14
9.6.2	Reply Format	14
9.7	PEEK (0x02)	15
9.7.1	Command Format	15
9.7.2	Reply Format	15
9.8	POKE (0x03)	15
9.8.1	Command Format	15
9.8.2	Reply Format	15
9.9	DIAGNOSTIC (0x04)	15
9.9.1	Command Format	15
9.9.2	Reply Format	15
9.10	CRC (0x06)	16
9.10.1.1	Command Format	16
9.10.1.2	Reply Format	16
9.11	READ FILE (0x07)	16
9.11.1	Command Format	16
9.11.2	Reply Format	16
9.11.2.1	Mode Reply Structure	16
9.11.2.2	Normal Reply Structure	16
9.12	WRITE FILE (0x08)	16
9.12.1	Command Format	17
9.12.1.1	Mode Store Structure	17
9.12.1.2	Normal Store Structure	17
9.12.1	Reply Format	17
9.12.1.1	Mode Reply Structure	17
9.12.1.2	Normal Reply Structure	17
9.13	READ EDAC (0x09)	17
9.13.1	Command Format	17
9.13.2	Reply Format	17
10	Protocol Layer 6 (Presentation Layer)	18
10.1	Fault State	18
10.2	Memory Map	18
10.3	Diagnostics	18
10.3.1	Reset Reason	19
10.3.2	Reset Count	19
10.3.3	Framing Error	19
10.3.4	Runt Packet	20
10.3.5	Oversize Packet	20
10.3.6	Bad CRC	20
10.4	EDAC Memory	20
10.4.1	Command Value	22
10.4.2	GROUND	22

10.4.3	VDD	22
10.4.4	TEMPERATURE	22
10.4.5	LDO	22
10.4.6	VSENSE	22
10.4.7	SPEED	22
10.4.8	MOMENTUM	22
10.4.9	SEU_COUNT	22
10.4.10	FAULT_STATE	22
10.4.11	HALL_DIGITAL	23
10.4.12	CONTROL_TIME	23
10.4.13	SPEED_[PI]D_GAIN	23
10.4.14	MIN_GAIN_SPEED, MAX_GAIN_SPEED	23
10.4.15	INERTIA	23
10.4.16	GAIN_SCHEDULE[1..4]	23
10.4.17	CONTROL_TYPE	24
10.4.18	MAX_SPEED_AGE	24
10.4.19	LIMIT_SPEED1	24
10.4.20	LIMIT_SPEED2	25
10.4.21	LIMIT_VOLTAGE	25
10.4.22	PREVIOUS_SPEED	25
10.4.23	SPEED_INTEGRATOR	25
10.4.24	SPEED_LAST_ERROR	25
10.4.25	ACCEL_TARGET	25
10.4.26	TEST_VOLTAGE	25
10.4.27	TORQUE_[T0..T4]	26
10.4.28	MODE	26
10.4.29	HALL_IMPOSSIBLE	26
10.4.30	HALL_SKIP	26
10.4.31	CONTROL_OVERFLOW	26
10.4.32	SFFT_STEP_NUMBER	26
10.4.33	SFFT_TELEM_COUNT	26
10.4.34	MODE_MONITOR	27
10.4.35	FRICTION_DONE	27
10.5	Command Modes	27
10.5.1	IDLE	28
10.5.2	PWM	28
10.5.3	VOLTAGE	28
10.5.4	SPEED	28
10.5.5	PWM_H[1..6]	28
10.5.6	VOLTAGE_H[1..6]	28
10.5.7	ACCEL	28
10.5.8	MOMENTUM	29
10.5.9	TORQUE	29
10.5.10	BURNIN	29
10.5.11	SFFT	29
10.5.12	LIFE	29

10.5.13	STORE_FILES.....	29
10.5.14	DEFAULT_FILES .....	29
10.5.15	PWM_P[0..2] .....	29
10.5.16	MEASURE_FRICTION .....	30
10.5.17	MEASURE_STICTION.....	30
10.5.18	SOAK.....	30
10.5.19	REPEAT.....	30
10.5.20	COMPLETE.....	30
10.5.21	AUX1 .....	30
10.5.22	AUX2 .....	30


## 1 Scope

This document details the mechanical, electrical and software interfaces for the smallest Sinclair Interplanetary reaction wheels. At present these include:

- RW-0.003-8-I2C

## 2 Mechanical


### 2.1 Overall Dimensions




The axes for the reaction wheel are defined as shown in the above figure. The rotation arrow shows the direction of wheel rotation that is considered positive wheel speed. Rotation in the opposite direction is considered negative wheel speed.

## 2.2 Mounting Holes

The wheel is mounted using the two unused corner holes as shown below. These holes are sized for #2-56 screws.



Of critical importance when mounting is that the wheel be supported beneath the two mounting points using a spacer or boss having a height of at least 3.2mm (1/8"). This ensures that the bottom of the wheel is not in direct contact with the spacecraft structure, which can cause warping of the wheel when the mounting screws are tightened. Such warping can impede proper function of the wheel.



## **2.3 Mass Properties**

The mass of the complete wheel assembly is approximately 47.5g. The mass center is close to the geometric center.

## **2.4 Remove Before Flight**

There are no necessary remove-before-flight elements. The bearings are covered with Kapton circles. These may be removed at the user's option, if the bearings are otherwise protected (such as mounting the wheel flush against a plate).

# **3 Environmental**

## **3.1 Storage**

The wheel must be stored in a clean environment to keep dust out of the bearings. The humidity must be kept low to prevent corrosion of the steel rotor. The wheel may be stored in a sealed bag with desiccant.

## **3.2 Thermal**

**Table 1: Allowable Temperature Range**

Survival Temperature	-40°C to +125°C
Operating Temperature (short term)	-40°C to +100°C at interface
Operating Temperature (long term)	-20°C to +70°C at interface

Table 1 shows the allowed temperature range for the wheel. Short term operating temperatures are permitted for periods of hours to days, while long term operating temperatures are permitted for the many years of a mission.

## **3.3 Pressure**

The wheel will operate in sea-level atmosphere and in hard vacuum. It has not been qualified to operate at high altitude atmospheres, and should not be powered during ascent unless additional testing is performed to show that there is no danger of arcing.

All materials meet the standard outgassing requirements of TML < 1%, CVCM < 0.1%.

## **3.4 Vibration**

The wheel is designed to survive typical launch environments.  
[Qualification environment TBD]

# **4 Electrical**

## **4.1 Polarized Nano**

The wheel is fitted with a 4 contact polarized nano connector. The pinouts for these connectors are liable to confusion. For clarity, use mating connector A79600-001 from Omnetics. The wire colours of that mating connector are:

**Table 2: Polarized Nano Connector**

Wire	Name
Black	Power In/Out
Brown	Ground
Red	SDA
Orange	SCL

## 4.2 Programming Header

There is a single plated through hole on the PCB that is accessed with a clip-lead during fabrication. It carries the signal “C2CK”, and is used for initial software load.

## 5 Signals

### 5.1 Power In/Out

Absolute Maximum	-0.3 V to +11.0 V
Operating Range	+5.0 V to +8.8 V
Front-end Capacitance	220 nF
Total Capacitance	43 uF
ESD Protection	Front end capacitor ESD qualified per HBM-AEC Q200-002.

The Power In/Out signal is used to power the reaction wheel. Power normally flows into the wheel, but during regeneration it is possible for power to flow out.

At +8.82 V nominal the overvoltage protection feature will reset the wheel from application to bootloader software. See the fault protection section for more information.

### 5.2 Ground

The ground signal is the return for the power signal, and is the reference for all of the other signals. Ground is connected to chassis through a bleed resistor (TBD) and RF capacitor (TBD).

### 5.3 SDA, SCL

Absolute Maximum	-0.5 V to +5.6 V
Input High Voltage	> 2.3 V
Input Low Voltage	< 1.0 V
Output Low Voltage	< 0.9 V @ 3 mA
Pullup Current	330 uA @ 0 V
ESD Rating	IEC 61000-4-2 model ±30 kV contact discharge ±30 kV air discharge


SDA and SCL comprise an I<sup>2</sup>C communications bus. The signals are not loaded if the wheel is powered down. The SCL signal is also used during factory programming.

## 5.4 C2CK

Absolute Maximum	-0.5 V to +5.6 V when wheel is powered -0.5 V to +2.5 V when wheel unpowered
Input High Voltage	> 2.2 V
Input Low Voltage	< 0.77 V
Pullup Current	3.3 mA @ 0 V
ESD Rating	IEC 61000-4-2 model ±30 kV contact discharge ±30 kV air discharge

C2CK is used during factory programming.

## 5.5 Power Architecture



**Figure 1: Power Architecture**

The wheel has a simple power architecture with only one power input. All of the voltage rails are produced by DC/DC conversion, giving greater efficiency.

## 5.6 Regenerative Braking

The wheel makes use of regenerative braking when slowing the rotor under moderate torque. This will result in the wheel consuming a net negative amount of power, pushing current back out onto the spacecraft power bus. The spacecraft power system design must be able to deal with this.

In an emergency, if the power line becomes disconnected from the power system (such as if turned off via a relay switch) regeneration will increase the voltage at the wheel until the  $\sim 8.82 V$  safety threshold is reached. This will cause the wheel to reset and cease regeneration.



## 6 Protocol Layer 2 (Data Link Layer)

### 6.1 I<sup>2</sup>C

The wheel uses a standard I<sup>2</sup>C communications bus. It acts as a bus slave, but will perform clock-stretching as needed.

If SCL is held low for 25 msec the interface will reset, as described in the SMBus specification.

### 6.2 Asynchronous Serial

Asynchronous serial is supported by the reaction wheel hardware, but not implemented by its software at this time. If used, the SDA signal becomes TX and the SCL signal becomes RX.

## 7 Protocol Layer 3 (Network Layer)

NSP is the Nanosatellite Protocol, originally developed at UTIAS/SFL for use on the CanX nanosatellites. This in turn is descended from the Simple Serial Protocol (SSP) used by UTIAS/SFL and Dynacon on the MOST and CHIPSAT spacecraft as well as the Dynacon reaction wheels in the wider market.

The reaction wheel uses NSP messages for all communication.

### 7.1 SLIP Encoding

NSP messages are encoded for transmission on asynchronous or I<sup>2</sup>C serial channels use SLIP framing, as described in RFC 105. This is required in order to indicate the beginning and end of NSP messages.

Table 3: SLIP Framing Special Characters

FEND	0xC0
FESC	0xDB
TFEND	0xDC
TFSEC	0xDD

Whenever FEND would occur within the message it is replaced by two bytes: FESC TFEND. Whenever FESC would occur within the message it is replaced by FESC TFESC.

### 7.2 I<sup>2</sup>C Encapsulation

NSP messages are encapsulated for transmission over I<sup>2</sup>C links. The NSP address of a device is also used as its I<sup>2</sup>C address – note that I<sup>2</sup>C addresses are only 7 bits long, while NSP implemented on other links will accept up to 8 bits.

Table 4: NSP Telecommand over I<sup>2</sup>C with no Reply

Transmitter	Data	Notes
OBC	START	
OBC	Slave address, Write	Slave ACK indicates slave receiving
OBC	Source address	

OBC	Message Control Field	Poll bit = 0
OBC	Outgoing data (0 – N bytes)	
OBC	16-bit CRC	
OBC	FEND	
OBC	STOP	

The table above shows the OBC (Onboard computer), which is also the bus master, sending a telecommand to a wheel where no reply is required. The message is SLIP framed, except that the leading FEND is omitted as it is redundant – I<sup>2</sup>C provides an out-of-band frame start signal.

The destination address is not transmitted. Instead, the transaction begins with the slave address and the write bit, in accordance with the I<sup>2</sup>C specification. Note that the CRC is computed based on the NSP message, not on the bytes transmitted over the I2C link.

**Table 5: NSP Telecommand over I2C with Reply**

Transmitter	Data	Notes
OBC	START	
OBC	Slave address, Write	Slave ACK indicates slave receiving
OBC	Source address	
OBC	Message Control Field	Poll bit = 1
OBC	Outgoing data (0 – N bytes)	
OBC	16-bit CRC	
OBC	FEND	
OBC	START	
OBC	Slave address, Read	Slave ACK indicates slave receiving
Wheel	Message Control Field	Poll bit = 1
Wheel	Reply data (0 – N bytes)	
Wheel	16-bit CRC	
Wheel	FEND	OBC sends NACK to reclaim control of SDA
OBC	STOP	

The table above shows the OBC sending a telecommand to a wheel where a reply is required. Instead of sending a STOP at the end of the telecommand, the OBC sends a repeated START. To comply with the I<sup>2</sup>C specification it must then re-send the slave address in read mode.

The slave then sends the reply message. This is SLIP framed, but as before the leading FEND is omitted. The destination and source address are also both omitted. An I2C transaction is atomic, so there can be no question of which telecommand produced which reply. Even though these fields are omitted, the CRC is still computed based on the entire NSP message in the normal fashion.

## 8 Protocol Layer 4 (Transport Layer)

### 8.1 NSP Message Format

**Table 6: NSP Message Fields**

Length	Field
--------	-------

1 byte	Destination Address
1 byte	Source Address
1 byte	Message Control Field
0 or more bytes	Data Field
2 bytes	Message CRC

Each NSP message has the format shown above. The shortest possible messages are 5 bytes (with zero data, not counting framing).

The wheel supports a maximum data length of 260 bytes, giving a total message length of 265 bytes. Note that network-layer framing may add additional bytes to the message as it is transmitted.

## 8.2 NSP Addresses

All NSP messages contain a destination and a source address. A reply message will be sent with a destination address equal to the source address of its command message. Similarly, the source address will be set equal to the destination address from the command.

The user is free to pick one or more NSP addresses for flight computers and other units that may talk to the wheel. Avoid choosing the SLIP framing characters FEND (0xC0) and FESC (0xDB), as well as the reserved address 0x00. By convention the flight computer would normally use NSP address 0x11.

The wheel pays no particular attention to the source address of commands, and will accept commands from any unit on the bus.

## 8.3 Message Control Field

Table 7: Message Control Field

Bit 7 (MSB)	“Poll/Final” Bit
Bit 6	“B” Bit
Bit 5	“ACK” Bit
Bits 4 – 0	Command code

The message control field packs four values into a single byte. The command code is an enumerated value between 0x00 and 0x1F that determines how the data field should be interpreted.

The “ACK” bit is ignored on commands coming into the wheel. On telemetry reply messages sent by the wheel it is set to indicate successful execution of the command, or cleared to indicate that the command cannot be executed.

The “B” bit is copied unchanged from a command message into its reply message. The wheel does not use it internally.

The “Poll/Final” bit is interpreted differently for command and telemetry messages. For a command, the bit is “Poll”. If it is set to ‘1’ then the wheel will generate a telemetry message in reply. If it is cleared to ‘0’ then the command will be executed, but no response telemetry message will be sent.

For a telemetry message, the bit is “Final”. If a reply consists of a single telemetry message, then the bit is set to ‘1’. If a reply is too large to fit into a single message then the final message has the bit set to ‘1’ and the others have the bit cleared to ‘0’.

## 8.4 Data Field

The interpretation of the data field is dependent on the command code in the message control field. Some command codes may have no data, some may require a certain fixed number of data bytes, and some can accept a variable data length.

## 8.5 Message CRC

Each NSP message contains a 2 byte (16-bit) CRC to guard against errors in transmission. The 16-bit CCITT polynomial is used:  $x^{16} + x^{12} + x^5 + 1$ . The initial shift register value is 0xFFFF. Bytes are fed into the CRC computation starting with the destination address, and concluding with the last byte of the data field. Within a byte, bits are fed in LSB first.

The following fragment of C code, courtesy of Henry Spencer, illustrates how the CRC can be computed.

```
#define POLY 0x8408 /* bits reversed for LSB-first */
unsigned short crc = 0xffff;
while (len-- > 0) {
    unsigned char ch = *bufp++;
    for (i = 0; i < 8; i++) {
        crc = (crc >> 1) ^ ( ((ch ^ crc) & 0x01) ? POLY : 0
        );
        ch >>= 1;
    }
}
```

## 8.6 Error Conditions

The wheel will ignore NSP command messages where the destination address does not correspond to its own NSP address. NSP messages with invalid CRC, invalid encapsulation, too short or too long are also ignored. In none of these cases will any reply message be generated.

If an NSP command message is in error due to an unknown command code, or if the data field is not consistent with the requirements of the command code, and if the “Poll” bit is set, then a NACK reply message will be generated. This message will be the same length as the command message, and contain the same data field. The command code will be the same, as will the “B” bit. The “ACK” bit will be cleared to ‘0’.

# 9 Protocol Layer 5 (Session Layer)

## 9.1 Operating Modes




Figure 2: Mode Transition Diagram

Power-on starts the unit in bootloader mode.

### 9.1.1 Bootloader to Application Transition

The wheel will transition from bootloader to application mode upon receipt of an “INIT 0x00001000” command.

### 9.1.2 Application to Bootloader Transition

The wheel will transition from application mode to bootloader mode under the following conditions:

- An “INIT” command with no data is received.
- The Power In/Out pin exceeds ~8.82 V.

## 9.2 Test Scripts

The reaction wheel contains a number of preprogrammed test scripts. These are used in the factory for initial characterization and pass/fail acceptance testing. They can also be used by customers to verify the health of the wheel during integration and on-orbit.

The exact contents of the test scripts is not documented here, to avoid the danger that it might become out of sync with the actual software. The *rw-bit-term* program should be used to record and interpret test script output. It is automatically synced to the wheel onboard software.

## 9.3 Byte Order

All multi-byte values transported in the data field of NSP messages are in little-endian format. That is, the least-significant byte is stored first, and the most-significant byte is stored last.

## 9.4 Command Codes

Table 8: Command Codes

Command Code	Command	Bootloader	Application
0x00	PING	Yes	Yes
0x01	INIT	Yes	Yes
0x02	PEEK	Yes	Yes
0x03	POKE	Yes	Yes
0x04	DIAGNOSTIC	Yes	Yes
0x06	CRC	Yes	Yes
0x07	READ FILE	No	Yes
0x08	WRITE FILE	No	Yes
0x09	READ EDAC	No	Yes

The table above shows the command codes that can be used by the host spacecraft to communicate with the wheel.

## 9.5 *PING (0x00)*

The PING command is typically used during testing to verify communications. Incoming data is ignored. The reply packet contains a human-readable text string containing:

- The type of device and the manufacturer
- The name, and compile time and date of the software that is currently running on the target processor.

### 9.5.1 Command Format

Bytes 0 – N	Zero or more bytes, ignored by the NSP module
-------------	---

### 9.5.2 Reply Format

Bytes 0 – N	Human-readable ASCII string. No NULL termination.
-------------	---

## 9.6 *INIT (0x01)*

The INIT command is used to change the operating mode of a wheel. In general, and INIT with data is interpreted as an address to jump to. An init with no data is interpreted as a reset or exit command. In all cases, if a reply has been requested (“Poll” bit set to ‘1’) then the reply will be sent before the processor state is changed.

The wheel will respond to an INIT with no data by completely resetting the device, returning to bootloader mode. If it is in bootloader mode, it will respond to an INIT with 4 bytes of data by running an Application Module at the corresponding 32-bit start address. By convention, devices will ship from the factory with the supervisor processor primary application program stored at address 0x00001000. Thus, a command of INIT 0x00001000 will start the default behaviour.

### 9.6.1 Command Format

Reboot command:

No payload bytes
------------------

Application start command:

Bytes 0 – 3	32-bit integer address of program to start
-------------	--

### 9.6.2 Reply Format

Reboot reply:

No payload bytes
------------------

Application start reply:

Bytes 0 – 3	32-bit integer address of program to be started
-------------	---

## 9.7 *PEEK (0x02)*

The PEEK command is used to read the device memory. The wheel processor has no restriction on the alignment or length of a peek.

### 9.7.1 Command Format

Bytes 0 – 3	32-bit address to start peeking data
Byte 4	Number of bytes to read. A value of 0 indicates that 256 bytes should be read.

### 9.7.2 Reply Format

Bytes 0 – 3	32-bit address of the start of data
Bytes 4 – N	One or more bytes read from the target memory

## 9.8 *POKE (0x03)*

The POKE command is used to write the device memory. The wheel will only permit a POKE into flash memory when in bootloader mode. Each 512 byte block of flash memory has a lifetime of only 20,000 write cycles. One cycle is consumed for each POKE command that accesses a particular block. This lifetime is more than sufficient for occasional software patches, but the user is cautioned that a looping sequence of POKE commands could easily wear out a block.

A single POKE command cannot span two flash blocks. This restriction comes from the SMBus 25 msec clock stretching limit – we cannot erase and program two flash blocks in this time.

### 9.8.1 Command Format

Bytes 0 – 3	32-bit address to start poking data
Byte 4 – N	1 - 256 bytes to write to the target memory

### 9.8.2 Reply Format

Bytes 0 – 3	32-bit address where data write began
Bytes 4 – N	1 – 256 bytes written to the target memory

## 9.9 *DIAGNOSTIC (0x04)*

The DIAGNOSTIC command gathers error count data from the wheel.

### 9.9.1 Command Format

Byte 0	Address of the diagnostic channel to read, as an 8-bit integer
--------	--

### 9.9.2 Reply Format

Byte 0	Address of the diagnostic channel read, as an 8-bit integer
Bytes 1 - 4	Diagnostic value from the addressed channel, as a 32-bit integer

## 9.10 CRC (0x06)

CRC command is used to calculate a checksum on an area of flash memory. The CRC uses the same 16-bit polynomial, with the same bit order, as is used for NSP messages.

The largest possible range is 0x0000 to 0xFBFF. This takes 17 msec to compute. Thus the computation is always compatible with the SMBus 25 msec clock stretch limit.

### 9.10.1.1 Command Format

Bytes 0 – 3	Address of the first byte to CRC as 32-bit integer
Bytes 4 – 7	Address of the last byte to CRC as 32-bit integer

### 9.10.1.2 Reply Format

Bytes 0 – 3	Address of the first byte in CRC as 32-bit integer
Bytes 4 – 7	Address of the last byte in CRC as 32-bit integer
Bytes 8 – 9	CRC result as 16-bit integer

## 9.11 READ FILE (0x07)

The Read File command returns one or more “files”, which are four consecutive bytes of EDAC protected memory. A read from address 0 is a special case, and an additional mode byte is returned.

### 9.11.1 Command Format

Bytes 0	EDAC address divided by 4 (0 – 255). 0 for mode, 1 – 255 for normal.
---------	--

### 9.11.2 Reply Format

Bytes 0-4 or 0-5	File Reply structure. The first byte of the structure determines its type.
------------------	--

#### 9.11.2.1 Mode Reply Structure

Byte 0	0
Byte 1	Command type read from EDAC
Bytes 2 - 5	Command value read from EDAC

#### 9.11.2.2 Normal Reply Structure

Byte 0	Non-zero EDAC address divided by 4 (1 – 255)
Bytes 1 - 4	EDAC data bytes read from memory

## 9.12 WRITE FILE (0x08)

The Write File command stores one “files”, which are four consecutive bytes of EDAC protected memory. A write to address 0 is a special case, and an additional mode byte is stored.



If a Write File command fails due to improper formatting then no modification to EDAC memory is made.

### 9.12.1 Command Format

Bytes 0-N	One File Store structures. The first byte of each structure determines its type.
-----------	--

#### 9.12.1.1 Mode Store Structure

Byte 0	0
Byte 1	Command type to store
Bytes 2 - 5	Command value to store

#### 9.12.1.2 Normal Store Structure

Byte 0	Non-zero EDAC address divided by 4 (1 – 255)
Bytes 1 - 4	Data bytes to write to EDAC memory

### 9.12.1 Reply Format

Bytes 0-4 or 0-5	File Reply structures. The first byte of each structure determines its type.
------------------	--

#### 9.12.1.1 Mode Reply Structure

Byte 0	0
Byte 1	Command type read from EDAC
Bytes 2 - 5	Command value read from EDAC

#### 9.12.1.2 Normal Reply Structure

Byte 0	Non-zero EDAC address divided by 4 (1 – 255)
Bytes 1 - 4	EDAC data bytes read from memory

## 9.13 *READ EDAC (0x09)*

The Read EDAC command returns bytes from EDAC memory. The read process is atomic.

### 9.13.1 Command Format

Bytes 0 – 1	EDAC address to start reading
Byte 2	Number of bytes to read. A value of 0 indicates that 256 bytes should be read.

### 9.13.2 Reply Format

Bytes 0 – 1	EDAC address where reading started
Bytes 2 – N	The data bytes read from EDAC memory

## 10 Protocol Layer 6 (Presentation Layer)

### 10.1 Fault State

Once in application mode, the reaction wheel may exist in or out of fault state. It starts out of fault state. Fault state is entered by the following conditions:

- Motor drive FET temperature exceeding  $\sim 160$  °C.
- Motor drive current exceeding  $\sim 2$  A.
- Rotor speed exceeding LIMIT\_SPEED2

In the fault state the motor is not driven. Fault state is exited by the following condition:

- Command to IDLE

### 10.2 Memory Map

Table 9: Supervisor Memory Map

Address Range	Function
0x00000000 – 0x00000FFF	Bootloader program memory
0x00001000 – 0x0000F3FF	Program memory (flash)
0x0000F400 – 0x0000F7FF	Stored parameters (flash)
0x0000FA00 – 0x0000FBFF	Bootloader program memory
0x0000FC00 – 0x0000FFBF	Reserved area, access forbidden
0x0000FFC0 – 0x0000FFCF	128-bit UUID
0x01000000 – 0x010000FF	256 B IRAM (RAM)
0x02000000 – 0x020000FF	4 kB XRAM (RAM)
0x03000080 – 0x030000FF	128 B SFR (RAM) Bank 00h
0x03100080 – 0x031000FF	128 B SFR (RAM) Bank 10h
0x03200080 – 0x032000FF	128 B SFR (RAM) Bank 20h
0x03300080 – 0x033000FF	128 B SFR (RAM) Bank 30h

The supervisor memory can be directly accessed with PEEK and POKE commands, and CRCs calculated with CRC commands. It is represented as a single 32-bit memory space, sparsely populated.

The first 4 kB of program memory contain the bootloader. These are protected against POKES so that the bootloader cannot be accidentally changed. The next 57 kB contains the supervisor application program. A sequence of POKE commands in bootloader mode can be used to load new application programs.

The bootloader memory cannot be read by the application program, and so PEEK or CRC commands to those regions will fail if not in bootloader mode.

The processor has two RAM areas. There is little need for a user to touch these.

There are four banks of Special Function Registers (SFRs). These should not be POKED without knowing exactly what is going on. Even PEEKing some of these registers can have unexpected side effects.

### 10.3 Diagnostics

The diagnostics contain a series of read-only integers that relate to the health of the wheel.

**Table 10: Diagnostic Channels**

Diagnostic Channel	Name
0x00	Reset Reason
0x01	Reset Count
0x02	Framing Errors
0x03	Runt Packets
0x04	Oversize Packets
0x05	Bad CRC

### 10.3.1 Reset Reason

The reset reason is an enumerated type, describing the reason for the most recent reset of the wheel processor.

**Table 11: Reset Reason Codes**

Reset Reason Code	Meaning
0	Power cycle. The wheel has either been freshly turned on, or the input voltage has drooped below the minimum operating voltage.
1	Realtime clock. This should not happen, as no realtime clock is fitted to this hardware.
2	Flash error. An illegal attempt has been made to read or write flash memory.
3	Comparator reset. This occurs if the Power In/Out pin exceeds 8.82 V.
4	Watchdog reset. The default application program does not use the watchdog timer, but if it somehow does get turned on this is the reset that it would generate.
5	Missing clock. The clock source for the processor stopped ticking.
6	Pin reset. The external C2CK signal has been pulled low. This should not happen to an integrated wheel.
7	Software reset. The most likely cause is that an INIT command has been received with no data, forcing a reset.

### 10.3.2 Reset Count

The reset count contains the number of wheel processor resets since the last power cycle reset. Immediately after a power cycle the reset count will read as 0. After the first non-power-cycle reset it will read 1.

### 10.3.3 Framing Error

A framing error is declared if an NSP message is incorrectly encapsulated on the communications link. This would be any time a FESC character is seen that is not immediately followed by TFESC or TFEND.

### 10.3.4 Runt Packet

A runt packet is a NSP message that is less than 5 bytes long. Such a fragment cannot be a properly formed NSP message since it cannot contain a source and destination address, control field, and CRC.

### 10.3.5 Oversize Packet

An oversize packet is one that has too many bytes in the data field. Packets that are too long cannot fit into the allocated message buffers and so they must be rejected. See section 8.1 for the length constraints.

### 10.3.6 Bad CRC

This count is incremented every time a properly formatted (in length and framing) NSP message is received where the CRC field does not match with the computed CRC, and where the first byte is equal to the NSP address of the wheel.

## 10.4 EDAC Memory

The wheel supports 1024 bytes of EDAC protected memory. These are implemented using software-based triple-redundant storage into conventional SRAM cells. EDAC memory can be read with READ EDAC and READ FILE commands, and written with WRITE FILE commands. The MODE\_STORE command will save EDAC memory into non-volatile flash memory.

**Table 12: EDAC Memory Contents**

EDAC Address	File Address	Function	Format
0x000 – 0x003	0x00	Command Value	Command Dependent
0x004 – 0x007	0x01	GROUND	Volts (IEEE-754 float)
0x008 – 0x00B	0x02	VDD	Volts (IEEE-754 float)
0x00C – 0x00F	0x03	TEMPERATURE	°C (IEEE-754 float)
0x010 – 0x013	0x04	LDO	Volts (IEEE-754 float)
0x014 – 0x017	0x05	VSENSE	Volts (IEEE-754 float)
0x054 – 0x057	0x15	SPEED	Rad/sec (IEEE-754 float)
0x058 – 0x05B	0x16	MOMENTUM	N-m/sec (IEEE-754 float)
0x060 – 0x063	0x18	SEU_COUNT	counts (IEEE-754 float)
0x064 – 0x067	0x19	FAULT_STATE	Enum in IEEE-754 float
0x06C – 0x06F	0x1B	HALL_DIGITAL	Binary value in IEEE-754 float

0x070 – 0x073	0x1C	CONTROL_TIME	Timer ticks (IEEE-754 float)
0x080 – 0x083	0x20	SPEED_P_GAIN	Amps / rad / sec (IEEE-754 float)
0x084 – 0x087	0x21	SPEED_I_GAIN	Amps / rad (IEEE-754 float)
0x088 – 0x08B	0x22	SPEED_D_GAIN	Amps / rad / sec <sup>2</sup> (IEEE-754 float)
0x094 – 0x097	0x25	MAX_GAIN_SPEED	Rad/sec (IEEE-754 float)
0x098 – 0x09B	0x26	MIN_GAIN_SPEED	Rad/sec (IEEE-754 float)
0x0A0 – 0x0A3	0x28	INERTIA	kg-m <sup>2</sup> (IEEE-754 float)
0x0A8 – 0x0AB	0x2A	GAIN_SCHEDULE1	(IEEE-754 float)
0x0AC – 0x0AF	0x2B	GAIN_SCHEDULE2	(IEEE-754 float)
0x0B0 – 0x0B3	0x2C	GAIN_SCHEDULE3	(IEEE-754 float)
0x0B4 – 0x0B7	0x2D	GAIN_SCHEDULE4	(IEEE-754 float)
0x0BC – 0x0BF	0x2F	CONTROL_TYPE	(IEEE-754 float)
0x0C8 – 0x0CB	0x32	MAX_SPEED_AGE	sec (IEEE-754)
0x0CC – 0x0CF	0x33	LIMIT_SPEED1	Rad/sec (IEEE-754)
0x0D0 – 0x0D3	0x34	LIMIT_SPEED2	Rad/sec (IEEE-754)
0x0D4 – 0x0D7	0x35	LIMIT_VOLTAGE	Volts (IEEE-754)
0x100 – 0x103	0x40	PREVIOUS_SPEED	Rad/sec (IEEE-754)
0x104 – 0x107	0x41	SPEED_INTEGRATOR	Amps (IEEE-754)
0x108 – 0x10B	0x42	SPEED_LAST_ERROR	Rad/sec (IEEE-754)
0x10C – 0x10F	0x43	ACCEL_TARGET	Rad/sec (IEEE-754)
0x110 – 0x113	0x44	TEST_VOLTAGE	Volts (IEEE-754)
0x12C – 0x12F	0x4B	TORQUE_T0	Nm (IEEE-754)
0x130 – 0x133	0x4C	TORQUE_T1	Nm (IEEE-754)
0x134 – 0x137	0x4D	TORQUE_T2	Nm (IEEE-754)
0x138 – 0x13B	0x4E	TORQUE_T3	Nm (IEEE-754)
0x13C – 0x13F	0x4F	TORQUE_T4	Nm (IEEE-754)
0x140 – 0x143	0x50	VALUE_MONITOR	Varies (IEEE-754)
0x144 – 0x147	0x51	SFFT_STEP_TIMER	sec (IEEE-754)
0x3F8		MODE	8-bit enum
0x3F9		HALL_IMPOSSIBLE	8-bit unsigned int
0x3FA		HALL_SKIP	8-bit unsigned int
0x3FB		CONTROL_OVERFLOW	8-bit unsigned int
0x3FC		SFFT_STEP_NUMBER	8-bit unsigned int
0x3FD		SFFT_TELEM_COUNT	8-bit unsigned int
0x3FE		MODE_MONITOR	8-bit enum
0x3FF		FRICITION_DONE	8-bit boolean

#### **10.4.1 Command Value**

Accessing file 0 causes an extra mode byte to be transferred. By writing to this file the mode of the wheel can be commanded. By reading this file the current mode can be determined. The modes are enumerated in section 10.4.32.

If this parameter is accessed through EDAC writes and reads instead of file reads and writes there is no explicit mode byte transferred. It is possible to read and write the number associated with the command, but this is not advised.

#### **10.4.2 GROUND**

The voltage sensed by the wheel's ADC when looking at a grounded input. Should be very close to zero. This is of very little interest outside of anomaly investigation.

#### **10.4.3 VDD**

The output of the wheel's +3.3 V DC/DC converter.

#### **10.4.4 TEMPERATURE**

The on-die temperature of the wheel's processor. This is factory calibrated, and should be accurate to within a few degrees.

#### **10.4.5 LDO**

The output of the wheel's +1.8 V Low Dropout regulator.

#### **10.4.6 VSENSE**

The voltage on the Power In/Out pin.

#### **10.4.7 SPEED**

This read-only parameter returns the speed of the rotor.

#### **10.4.8 MOMENTUM**

This read-only parameter returns the angular momentum of the rotor. It is derived from the SPEED multiplied by INERTIA.

#### **10.4.9 SEU\_COUNT**

This parameter records the number of errors that have been found during EDAC scrubbing. Any error in a byte is considered to be a single error – no attempt is made to determine how many bits were flipped.

This parameter can be read to determine the error count. It can also be written – typically to reset it to zero.

#### **10.4.10 FAULT\_STATE**

This is 1.0 if the wheel is in a fault state, or 0.0 otherwise.

#### 10.4.11 HALL\_DIGITAL

The wheel has three Hall-effect sensors (numbered 0 to 2), each one generating a binary value. The value of these three bits is encoded into this parameter.

Hall 2	Hall 1	Hall 0	HALL_DIGITAL
0	0	0	0.0
0	0	1	1.0
0	1	0	2.0
0	1	1	3.0
1	0	0	4.0
1	0	1	5.0
1	1	0	6.0
1	1	1	7.0

#### 10.4.12 CONTROL\_TIME

This parameter not currently fully functional.

See the CONTROL\_OVERFLOW file for indication of negative realtime margin.

#### 10.4.13 SPEED\_[P|I|D]\_GAIN

These parameters set the gains for the PID closed-loop speed controller. See CONTROL\_TYPE for more information on when these are read-write parameters set by the user, and when they are read-only and internally generated.

#### 10.4.14 MIN\_GAIN\_SPEED, MAX\_GAIN\_SPEED

These read/write parameters bound the speed used as an input to the speed controller gain formula.

By setting these two parameters to the same value the speed dependence of the gains can be effectively disabled.

#### 10.4.15 INERTIA

This read/write parameter sets the rotor inertia. It is used to scale between acceleration and torque, and momentum and speed.

#### 10.4.16 GAIN\_SCHEDULE[1..4]

These four read/write parameters are used to set the speed control gains, in those cases when PROPORTIONAL\_OVERRIDE is zero. First, the characteristic speed  $\omega$  is determined based on the actual and setpoint speeds and on MAX\_GAIN\_SPEED and MIN\_GAIN\_SPEED.

$$\omega = \text{MIN}\left(\text{MAX}\left(|\omega_{actual}|, |\omega_{target}|, \omega_{MIN}\right), \omega_{MAX}\right)$$

The critical gain and period are modeled as a function of the characteristic speed. The four GAIN\_SCHEDULE parameters are written as G1..G4.

$$K_u = G_2 \cdot \omega^{G_1}$$

$$P_u = G_4 \cdot \omega^{G_3}$$

#### 10.4.17 CONTROL\_TYPE

This read/write parameter is used to determine the control type, using the Ziegler-Nichols method.

The value stored in CONTROL\_TYPE is truncated to an integer.

If the value is negative, then SPEED\_P\_GAIN, SPEED\_I\_GAIN and SPEED\_D\_GAIN are read-write parameters, set by the user.

If the value is 1, a PI controller is used:

$$K_p = 0.45 \cdot K_u$$

$$K_i = 1.2 \cdot K_p / P_u$$

$$K_d = 0.0$$

If the value is 2, a PID controller is used:

$$K_p = 0.6 \cdot K_u$$

$$K_i = 2.0 \cdot K_p / P_u$$

$$K_d = 0.125 \cdot K_p P_u$$

In the case of any other value, a P controller is used:

$$K_p = 0.5 \cdot K_u$$

$$K_i = 0.0$$

$$K_d = 0.0$$

#### 10.4.18 MAX\_SPEED\_AGE

This read/write parameter determines which digital Hall sensor transitions are used to determine the SPEED telemetry. Transitions are discarded if they are older than MAX\_SPEED\_AGE in time, if a complete rotor revolution has occurred since them, or if a rotor direction reversal is detected.

MAX\_SPEED\_AGE is relevant at very low rotor speeds. A larger value will allow more Hall sensor transitions to be used, giving a less noisy speed estimate. However, it will also increase the latency in speed measurements which may cause closed-loop speed control modes to become unstable.

#### 10.4.19 LIMIT\_SPEED1

This read/write parameter sets the maximum speed that closed-loop modes will target. The magnitude of the speed target used in speed, torque, momentum and acceleration modes is clamped to this value. This is particularly significant in torque and acceleration modes – if communication with the flight computer is lost for any reason the rotor will slowly accelerate until this limit is reached.



#### **10.4.20 LIMIT\_SPEED2**

This read/write parameter sets the absolute maximum speed that the wheel can reach. If the rotor exceeds this speed the fault state will be entered. LIMIT\_SPEED2 is active in all modes, which is significant since LIMIT\_SPEED1 is not effective in open-loop modes (PWM, VOLTAGE, etc).

#### **10.4.21 LIMIT\_VOLTAGE**

This read/write parameter sets the greatest voltage that can be impressed upon the motor by the drive stages.

By setting this lower than the smallest expected bus voltage, the wheel behaviour can be made insensitive to its supply. In this way, the same performance will be achieved with the spacecraft battery discharged or charged.

Lowering this parameter will also lower the maximum possible speed of the wheel, and reduce the maximum current consumed in a slew.

#### **10.4.22 PREVIOUS\_SPEED**

This read-only parameter contains the SPEED file from the previous control frame. It is expected that it might be used in the future to generate torque telemetry, but at present it is unused.

#### **10.4.23 SPEED\_INTEGRATOR**

This parameter contains the closed-loop controller integrator, scaled in amps of actuation. It is technically a read/write parameter, and it is possible for the user to write this for test purposes.

#### **10.4.24 SPEED\_LAST\_ERROR**

This read-only parameter contains the controller error from the previous control frame. It is used with the differential gain term of the closed-loop controller.

#### **10.4.25 ACCEL\_TARGET**

This parameter contains the speed setpoint used by the acceleration controller. The controller will add the acceleration to this file each frame. It is technically a read/write parameter, and it is possible for the user to write this as a way to force a new speed while remaining in acceleration/torque mode.

#### **10.4.26 TEST\_VOLTAGE**

This read-only parameter contains test information related to motor drive voltage. In a voltage controlled mode (such as SPEED) this contains the current motor voltage setting. It can be used to see the output of the closed-loop controller. After a MEASURE\_FRICTION or MEASURE\_STICTION command, this contains the minimum voltage required to maintain motion, or the minimum voltage required to break stiction, respectively.

#### **10.4.27 TORQUE\_[T0..T4]**

These five read-only parameters record the instantaneous torques measured in the last five control frames. T0 is the result of the most recent control frame. T4 is four frames old. The torque is computed as:

$$\text{TORQUE} = \text{INERTIA} * (\text{SPEED} - \text{PREVIOUS\_SPEED}) * 93 \text{ Hz}$$

Torque telemetry at low speed should be used with caution. The speed estimate is only updated when new hall sensor pulses are seen (or a very long period elapses). If there has been no hall sensor pulse in the previous control frame then  $\text{SPEED} == \text{PREVIOUS\_SPEED}$  and so  $\text{TORQUE} == 0$ .

#### **10.4.28 MODE**

This parameter stores the wheel's current mode. It is more often accessed through file 0, where the mode and command value can be read or written simultaneously.

#### **10.4.29 HALL\_IMPOSSIBLE**

This value counts the number of times that a transition to an "impossible" digital Hall-effect sensor configuration is seen. Impossible configurations are all "0", or all "1". This is an error condition, and would normally indicate failure of a sensor or loss of a rotor magnet. It is read/write, and can be written as zero to reset the count. The count range is 0..255. If an impossible configuration occurs with the count at 255 it will cycle back to 0.

#### **10.4.30 HALL\_SKIP**

This value counts the number of times that a Hall-effect sensor pattern transitions to another pattern that should not be immediately adjacent. Adjacent sensor patterns are those that differ by only one bit.

#### **10.4.31 CONTROL\_OVERFLOW**

This value counts the number of control frames where the control algorithm has not finished processing before the start of the next frame. This is an error condition, and would be expected to result in poor control. It is read/write, and can be written as zero to reset the count. The count range is 0..255. If a control overflow occurs with the count at 255 it will cycle back to 0.

#### **10.4.32 SFFT\_STEP\_NUMBER**

This value contains the step number of the current script that is being executed. It is not intended for this to be written to effect a goto behaviour.

#### **10.4.33 SFFT\_TELEM\_COUNT**

This value contains the offset from the start of the script telemetry at which the latest script telemetry will be written.

### 10.4.34 MODE\_MONITOR

This value contains the effective mode command that is currently being commanded by a script. Its value outside of script execution is not updated.

### 10.4.35 FRICTION\_DONE

This Boolean value is used internally by MEASURE\_FRICTION and MEASURE\_STICTION modes to signal when the rotor has stopped, or started, respectively.

## 10.5 Command Modes

Command Number	Command Name	Command Value
0x00	IDLE	Ignored
0x01	PWM	Duty cycle (-1.0 to +1.0)
0x02	VOLTAGE	Volts (-10 to +10)
0x03	SPEED	Rads/sec
0x04	PWM_H1	Duty cycle (-1.0 to +1.0)
0x05	PWM_H2	Duty cycle (-1.0 to +1.0)
0x06	PWM_H3	Duty cycle (-1.0 to +1.0)
0x07	PWM_H4	Duty cycle (-1.0 to +1.0)
0x08	PWM_H5	Duty cycle (-1.0 to +1.0)
0x09	PWM_H6	Duty cycle (-1.0 to +1.0)
0x0A	VOLTAGE_H1	Volts (-10 to +10)
0x0B	VOLTAGE_H2	Volts (-10 to +10)
0x0C	VOLTAGE_H3	Volts (-10 to +10)
0x0D	VOLTAGE_H4	Volts (-10 to +10)
0x0E	VOLTAGE_H5	Volts (-10 to +10)
0x0F	VOLTAGE_H6	Volts (-10 to +10)
0x10	ACCEL	Rads/sec <sup>2</sup>
0x11	MOMENTUM	N-m-sec
0x12	TORQUE	N-m
0x13	BURNIN	Final test step #
0x14	SFFT	Final test step #
0x15	LIFE	Final test step #
0x16	STORE_FILES	0.0 or 1.0
0x17	DEFAULT_FILES	0.0 or 1.0
0x18	PWM_P0	Duty cycle (-1.0 to +1.0)
0x19	PWM_P1	Duty cycle (-1.0 to +1.0)
0x1A	PWM_P2	Duty cycle (-1.0 to +1.0)
0x1B	MEASURE_FRICTION	Volts/sec
0x1C	MEASURE_STICTION	Volts/sec
0x1F	SOAK	Final test step #
0x20	REPEAT	Ignored
0x21	COMPLETE	Ignored

0x24	AUX1	Final test step #
0x25	AUX2	Final test step #

### **10.5.1 IDLE**

In IDLE mode the motor drive is turned off. If it is spinning, the rotor is free to slow down under friction.

### **10.5.2 PWM**

In PWM mode the motor is driven with a constant duty cycle. The command may be between -1.0 and 1.0. This is interpreted as a duty cycle between 0.0 and 1.0, in either the positive or negative direction.

PWM mode does not use closed-loop current or speed control, so it is not of great use in spacecraft fine control. However it does allow for extremely high torques (and very high power consumption!), so it may be used open-loop during slew maneuvers.

### **10.5.3 VOLTAGE**

In VOLTAGE mode the motor is driven with a constant voltage. The desired voltage is divided by the VSENSE telemetry measurement to determine the PWM duty cycle. This mode is open-loop, in a manner similar to PWM mode, but has feed-forward compensation against supply voltage variations.

### **10.5.4 SPEED**

In SPEED mode the rotor speed is servoed to the command value. The closed-loop speed controller outputs a voltage setpoint, which is in turn used by the voltage controller.

### **10.5.5 PWM\_H[1..6]**

In these modes the digital Hall-effect sensors are overridden, and the binary code is set to the H1..H6 value. Other than that, the mode is identical to PWM mode. It allows a particular PWM duty cycle to be driven onto a particular motor phase regardless of the rotor position. The rotor will typically not spin in these modes, but will oscillate about a particular electrical angle.

### **10.5.6 VOLTAGE\_H[1..6]**

In these modes the digital Hall-effect sensors are overridden, and the binary code is set to the H1..H6 value. Other than that, the mode is identical to VOLTAGE mode. It allows a particular voltage to be driven onto a particular motor phase regardless of the rotor position. The rotor will typically not spin in these modes, but will oscillate about a particular electrical angle.

### **10.5.7 ACCEL**

When not in ACCEL mode, the ACCEL\_TARGET file is set to SPEED. In ACCEL mode, the acceleration command is added to ACCEL\_TARGET each control frame. ACCEL\_TARGET is then used as the setpoint for the speed mode controller.

### **10.5.8 MOMENTUM**

In MOMENTUM mode, the SPEED controller is used with a setpoint equal to the commanded MOMENTUM divided by the INERTIA file.

### **10.5.9 TORQUE**

In TORQUE mode, the ACCEL controller is used with a setpoint equal to the commanded TORQUE divided by the INERTIA file.

### **10.5.10 BURNIN**

The BURNIN mode starts a test script intended to bring the bearing lubricant to a steady-state initial condition. Details are TBD.

### **10.5.11 SFFT**

The SFFT mode starts a test script to fully evaluate the health of an integrated reaction wheel. It concentrates on speed capacity, torque capacity, EMF characterization and friction characterization. Closed-loop control performance is not investigated.

The test will run for a number of minutes before terminating. All of the result data is stored in the parameter file. Consult the factory for automated software that will generate pass/fail reports.

### **10.5.12 LIFE**

The LIFE mode starts a test script intended for long-term operation on a life-test reaction wheel. Details are TBD.

### **10.5.13 STORE\_FILES**

If the STORE\_FILES mode is entered with a value of exactly 1.0, all of the parameters will be stored to non-volatile flash memory. The mode value will be set to 0.0, to indicate that the write has occurred and to prevent multiple writes. Whenever the wheel resets it will start with the stored parameters.

This mode does not drive the motor, and is equivalent in that way to IDLE.

### **10.5.14 DEFAULT\_FILES**

If the DEFAULT\_FILES mode is entered with a value of exactly 1.0 the stored parameters in non-volatile flash memory are erased. The mode value will be set to 0.0, to indicate that the erasure has occurred and to prevent multiple erasures. Whenever the wheel resets it will start with default parameters. This command has no effect on the parameters currently in the wheel parameter file, only on the parameters after the next reset.

This mode does not drive the motor, and is equivalent in that way to IDLE.

### **10.5.15 PWM\_P[0..2]**

The PWM\_P[0..2] modes allow the duty cycle of a particular motor phase (0..2) to be set. Only the one phase is driven, and none of the phases is connected to ground.

### **10.5.16 MEASURE\_FRICTION**

The MEASURE\_FRICTION mode should be entered with the wheel spinning, driven in a voltage-based mode (VOLTAGE, SPEED, etc). The drive voltage is slowly reduced, at a number of volts/second dictated by the mode value. Eventually the voltage will be so low that the rotor will stop.

As soon as the rotor speed reads 0.0 rad/sec, the TEST\_VOLTAGE parameter will stop updating. Thus, by reading TEST\_VOLTAGE the lowest voltage consistent with rotation can be determined. The HALL\_DIGITAL parameter can also be read, to determine the electrical angle at which the rotor stopped.

### **10.5.17 MEASURE\_STICTION**

The MEASURE\_STICTION mode should be entered with the wheel stopped, driven in a voltage-based mode (VOLTAGE, SPEED, etc). The drive voltage is slowly increased, at a number of volts/second dictated by the mode value. The sign of the mode value indicates whether the voltage should become positive or negative.

As soon as the rotor speed becomes non-zero, the TEST\_VOLTAGE parameter will stop updating. Thus, by reading TEST\_VOLTAGE the lowest voltage consistent with breaking stiction can be determined.

### **10.5.18 SOAK**

The SOAK mode starts a test script intended to facilitate the 120 hour high-temperature burn-in test. It is expected that the electronics unit will be connected to a stator, but there will not be a rotor. The mode drives current through each of the motor phases in turn and logs analog telemetry.

Not presently implemented.

### **10.5.19 REPEAT**

This mode exists as a flag within a script, indicating that the script should return to the first step. It is not a mode that can be usefully commanded by a user.

### **10.5.20 COMPLETE**

This mode exists as a flag within a script, indicating that the script should terminate. It is not a mode that can be usefully commanded by a user.

### **10.5.21 AUX1**

The AUX1 mode starts a test script to investigate closed-loop control performance through zero speed crossings.

The test will run for a number of minutes before terminating. All of the result data is stored in the parameter file. Consult the factory for automated software that will generate pass/fail reports.

### **10.5.22 AUX2**

The AUX2 mode starts a test script to investigate closed-loop control performance to step acceleration commands at different wheel speeds.

The test will run for a number of minutes before terminating. All of the result data is stored in the parameter file. Consult the factory for automated software that will generate pass/fail reports.